


BUTTON MAPPING: ALPHA LITE



INSTRUCTIONS


1. Go to settings (top right)




2. Go to "Controls"
3. Choose "Alpha Lite" from the "Device List" on the left side
4. Click on the settings icon next to "General controls" below "Alpha Lite presets config"
5. Click on "Create"



6. Put in a name for the profile (e.g. Alpha Lite - Standard)



7. Check both checkboxes on the right (Apply to all airplanes)
8. Click "OK"
9. Type in the function you want to map. In case of functionality of button 1: type in "toggle smart camera" (it will live filter results), click on the scanning field and push button 1 on the Alpha lite



10. Repeat for all functions listed on the right

FUNCTIONS

CAMERA

COCKPIT CAMERA

- Toggle smart camera: Joystick Button 1
- Reset cockpit view: Joystick Button 1
- Previous pilot position: Joystick POV down
- Next pilot position: Joystick POV up
- Cockpit quickview right: Joystick POV right
- Cockpit quickview left: Joystick POV left

INSTRUMENT VIEWS

- Previous instrument view: Joystick POV left
- Next instrument view: Joystick POV right

EXTERNAL CAMERA

- Reset external view: Joystick Button 2
- External quickview top: Joystick POV up
- External quickview right: Joystick POV left
- External quickview rear: Joystick POV down
- External quickview left: Joystick POV right

CAMERA MODE SWITCHES

- Cockpit / External view mode: Joystick Button 3

FLIGHT CONTROL SURFACES

PRIMARY CONTROL SURFACES

- Elevator Axis: Joystick L-Axis Y
- Ailerons Axis: Joystick L-Axis X

AUTOPILOT

- Toggle autopilot master: Joystick Button 4

CONTROL TRIMMING SURFACES

- Elevator trim up (nose up): Joystick Button 5
- Elevator trim down (nose down): Joystick Button 6
- Aileron trim right: Joystick Button 10
- Aileron trim left: Joystick Button 9

